

UNIVERSAL 12 IN 1

Model: URC22B-12

FOR TV/TXT-VCR-SAT/DSS/CABLE-HIFI-CD-LD/VCD/DVD-AUX:

Manual Programming:

- 1-put batteries in the control and turn on the TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX and point the control at it
- 2-look at the name of the TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX in the codes table and see its code
- 3-press (set) then (TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX) at the same time the indicator lights up
- 4-enter the code you need the light will go off
- 5-try the control

Auto Programming:

- 1-put batteries in the control and turn on the TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX and point the control at it
- 2-press and hold (SET) and (POWER) until indicator lights up
- 3-watch the TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX and when the device power off press any key except (SET) immediately

Note: you have to press any key except (SET) directly when the device power off

- 4-try the control if it did not work good repeat the operation again



برمجة يدوية:

- 1-ضع البطاريات وشغل TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX وصوب الجهاز نحوه
- 2-إبحث عن إسم TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX في جدول الكودات
- 3-إضغط (SET) و (TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX) في نفس الوقت سيضيئ الريموت
- 4-أدخل الكود المطلوب ستطفئ الريموت
- 5-جرب الريموت

برمجة آلية:

- 1-ضع البطاريات وشغل TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX وصوب الجهاز نحوه
- 2-إضغط (SET) و (POWER) بشكل مستمر إلى أن يضيئ الريموت
- 3-راقب TV/TXT or VCR or SAT or DSS or CABLE or HIFI or CD or LD/VCD/DVD or AUX وعندما يطفئ الجهاز إضغط (SET) بسرعة
- ملاحظة: يجب عليك ضغط (SET) مباشرة عندما يطفئ الجهاز
- 4-جرب الريموت إذا لم يعمل الريموت جيذا أعد العملية من جديد

