


40Hz Ultrasonic Range Detection Sensor

Model:DYP-ME007V1



Module Working Principle:


- (1) Adopt IO trigger through supplying at least 10us sequence of high level signal,
- (2) The module automatically send eight 40khz square wave and automatically detect whether receive the returning pulse signal,
- (3) If there is signals returning, through outputting high level

and the time of high level continuing is the time of that from the ultrasonic transmitting to receiving.

Test distance = (high level time * sound velocity (340M/S) / 2,

The circuit:

Very, very simple circuit, I've used the breadboard to share the GND connection and to add the LED which I could probably have done with out the breadboard. You'll see the most complex thing is the code later on.



The sketch:

All the work is done here, I've added code that averages the distance readings to remove some of the jitter in the results as the DYP-ME007 is calculating distances very rapidly and there can be a lot of fluctuation. Also I convert the time in microseconds to distance by dividing the time by 58.

Why 58? Well because if you take the time in microseconds for a pulse to be sent and received e.g. for 1 meter it takes about 5764 microseconds – at least from my wall anyway. If I divide this time by the distance in cm in I will get 57.64 so I just round this up – you can calculate distance in any other unit with this method.

Here I've also decided that for every cm under 255 my LED will get 1 step brighter. I've been lazy here for the sake of the sensors 3 metre range I didn't see the point in making this any more complicated. Otherwise I would calculate the brightness on the percentile of proximity out of total range.

Official test Code Example - 1:

```
#include <c8051f020.h>

#define uchar unsigned char
#define uint unsigned int

sbit P0_0=P0^0;
sbit P0_1=P0^1;
bit flag;

void delay(uint z)
{
    uint x,y;
    for(x=z;x>0;x--)
        for(y=0;y<110;y++);
}

void T0T1_Init()
{
    CKCON=0x00;
    TMOD=0x11;
    TH0=(65535-25)/256;
    TL0=(65535-25)%256;
    TH1=0;
    TL1=0;
    TR0=0;
    TR1=0;
    ET0=1;
    ET1=1;
    EA=1;
}
```

```

void main()
{
    WDTCN = 0xde;
    WDTCN = 0xad;
    // OSCXCN=0x67;
    // delay(100);
    // OSCICN=0x08;
    P0MDOUT=0x00;
    flag=0;
    P0_1=0;
    P0_0=1;

    T0T1_Init();

    // P1MDOUT=0xff;
    // P3MDOUT=0xFF;
    P74OUT=0xff;
    P4=0x01;

    XBR2=0x40;
    XBR1=0x04;
    // duan=0;
    // wei=0;

    P0_1=1;
    TR0=1;
    while(!flag);
    TR0=0;
    P0_1=0;
    flag=0;
    while(!P0_0);
    TR1=1;
    IT0=1;
    EX0=1;
    while(1)
    {
    }
}

```

```

void INT0_ISR() interrupt 0
{
    //EA=0;
    TR1=0;
    //delay(8000);
    P4=(P4<<1|P4>>(8-1));
    //TH1=0;
    // TL1=0;
    // a=(TH1*256+TL1)*0.017;
    // bai=
    /* for(j=0;j<6;j++)
    {
        wei=1;
        P1=table1[j];
        wei=0;

        duan=1;
        P1=table[j];
        duan=0;
        delay(2000);
    } */
}

```

```

void T0_ISR() interrupt 1
{
    TH0=(65535-25)/256;
    TL0=(65535-25)%256;
    flag=1;
}

```

Official test Code Example - 2:

```

// variables to take x number of readings and then average them
// to remove the jitter/noise from the DYP-ME007 sonar readings
const int numOfReadings = 10; // number of readings to take/ items in the
array
int readings[numOfReadings]; // stores the distance readings in an array
int arrayIndex = 0; // arrayIndex of the current item in the
array
int total = 0; // stores the cumulative total
int averageDistance = 0; // stores the average value
// setup pins and variables for DYP-ME007 sonar device
int echoPin = 2; // DYP-ME007 echo pin (digital 2)
int initPin = 3; // DYP-ME007 trigger pin (digital 3)
unsigned long pulseTime = 0; // stores the pulse in Micro Seconds
unsigned long distance = 0; // variable for storing the distance (cm)
// setup pins/values for LED
int redLEDPin = 9; // Red LED, connected to digital PWM
pin 9
int redLEDValue = 0; // stores the value of brightness for the
LED (0 = fully off, 255 = fully on)

```

```

//setup
void setup() {
    pinMode(redLEDPin, OUTPUT);           // sets pin 9 as output
    pinMode(initPin, OUTPUT);             // set init pin 3 as output
    pinMode(echoPin, INPUT);              // set echo pin 2 as input
    // create array loop to iterate over every item in the array
    for (int thisReading = 0; thisReading < numOfReadings; thisReading++) {
readings[thisReading] = 0;
    }
// initialize the serial port, lets you view the
// distances being pinged if connected to computer
    Serial.begin(9600);
}
// execute
void loop() {
    digitalWrite(initPin, HIGH);           // send 10 microsecond pulse
    delayMicroseconds(10);                 // wait 10 microseconds before turning off
    digitalWrite(initPin, LOW);            // stop sending the pulse
    pulseTime = pulseIn(echoPin, HIGH);     // Look for a return pulse, it should be high
as the pulse goes low-high-low
    distance = pulseTime/58;                // Distance = pulse time / 58 to convert to
cm.
    total= total - readings[arrayIndex];    // subtract the last distance
    readings[arrayIndex] = distance;        // add distance reading to array
    total= total + readings[arrayIndex];    // add the reading to the total
    arrayIndex = arrayIndex + 1;            // go to the next item in the array
// At the end of the array (10 items) then start again
    if (arrayIndex >= numOfReadings) {
        arrayIndex = 0;
    }
    averageDistance = total / numOfReadings; // calculate the average distance
    // if the distance is less than 255cm then change the brightness of the LED
    if (averageDistance < 255) {
        redLEDValue = 255 - averageDistance; // this means the smaller the distance the
brighterthe LED.
    }
    analogWrite(redLEDPin, redLEDValue);    // Write current value to LED pins
    Serial.println(averageDistance, DEC);    // print out the average distance to the
debugger
    delay(100);                             // wait 100 milli seconds before looping
again
}

```

Official test Code Example - 3:

```
////////////////////////////////////
//
// PIC16F877 + DYP-ME007 + LCD03 example
// Written October 2005 by Gerald Coe, using HITECH PIC16 compiler
//
// Note - assumes a 20MHz crystal, which is 5MHz timer clock
// A 1:4 prescaler is used to give a 1.25MHz timer count (0.8uS per tick)
//
// This code is Freeware - Use it for any purpose you like.
//
////////////////////////////////////

#include <pic.h>
#include <stdio.h>
__CONFIG(0x3b32);

#define trig RB0
#define echo RB1

void clrscn(void); // prototypes
void cursor(char pos);
void print(char *p);
void setup(void);
unsigned int get_srf04(void);

char s[21]; // buffer used to hold text to print

void main(void)
{
    unsigned int range;
    setup(); // sets up the PIC16F877 I2C port
    clrscn(); // clears the LCD03 display
    cursor(2); // sets cursor to 1st row of LCD03
    sprintf(s,"SRF04 Ranger Test"); // text, printed into our buffer
    print(s); // send it to the LCD03

    while(1) { // loop forever
        range = get_srf04(); // get range from srf04 (round trip flight
time in 0.8uS units)
        cursor(24); // sets cursor to 2nd row of LCD03
        sprintf(s,"Range = %dcm ", range/72); // convert to cm
        print(s); // send it to the LCD03
        cursor(44); // sets cursor to 3rd row of LCD03
        sprintf(s,"Range = %dinch ", range/185); // convert to inches
        print(s); // send it to the LCD03
    }
}
```

```

    TMR1H = 0; // 52mS delay - this is so that the
SRF04 ranging is not too rapid
    TMR1L = 0; // and the previous pulse has faded
away before we start the next one
    T1CON = 0x21; // 1:4 prescale and running
    TMR1IF = 0;
    while(!TMR1IF); // wait for delay time
    TMR1ON = 0; // stop timer
}
}

```

```

unsigned int get_srf04(void)
{
    TMR1H = 0xff; // prepare timer for 10uS pulse
    TMR1L = -14;
    T1CON = 0x21; // 1:4 prescale and running
    TMR1IF = 0;
    trig = 1; // start trigger pulse
    while(!TMR1IF); // wait 10uS
    trig = 0; // end trigger pulse
    TMR1ON = 0; // stop timer

    TMR1H = 0; // prepare timer to measure echo pulse
    TMR1L = 0;
    T1CON = 0x20; // 1:4 prescale but not running yet
    TMR1IF = 0;
    while(!echo && !TMR1IF); // wait for echo pulse to start (go high)
    TMR1ON = 1; // start timer to measure pulse
    while(echo && !TMR1IF); // wait for echo pulse to stop (go low)
    TMR1ON = 0; // stop timer
    return (TMR1H<<8)+TMR1L; // TMR1H:TMR1L contains flight time of the pulse
in 0.8uS units
}

```

```

void clrscn(void)
{
    SEN = 1; // send start bit
    while(SEN); // and wait for it to clear

```

```

    SSPIF = 0;
    SSPBUF = 0xc6; // LCD02 I2C address
    while(!SSPIF); // wait for interrupt
    SSPIF = 0; // then clear it.

```

```

    SSPBUF = 0; // address of register to write to
    while(!SSPIF); //
    SSPIF = 0; //

```

```

    SSPBUF = 12; // clear screen
    while(!SSPIF); //
    SSPIF = 0; //

```

```

    SSPBUF = 4; // cursor off
    while(!SSPIF); //
    SSPIF = 0; //
}

    PEN = 1; // send stop bit
    while(PEN); //
}

void cursor(char pos)
{
    SEN = 1; // send start bit
    while(SEN); // and wait for it to clear

    SSPIF = 0;
    SSPBUF = 0xc6; // LCD02 I2C address
    while(!SSPIF); // wait for interrupt
    SSPIF = 0; // then clear it.

    SSPBUF = 0; // address of register to write to

    while(!SSPIF); //
    SSPIF = 0; //

    SSPBUF = 2; // set cursor
    while(!SSPIF); //
    SSPIF = 0; //
    SSPBUF = pos; //
    while(!SSPIF); //
    SSPIF = 0; //

    PEN = 1; // send stop bit
    while(PEN); //
}

void print(char *p)
{
    SEN = 1; // send start bit
    while(SEN); // and wait for it to clear

    SSPIF = 0;
    SSPBUF = 0xc6; // LCD02 I2C address
    while(!SSPIF); // wait for interrupt
    SSPIF = 0; // then clear it.

    SSPBUF = 0; // address of register to write to
    while(!SSPIF); //
    SSPIF = 0; //

```

```

while(*p) {
    SSPBUF = *p++;           // write the data
    while(!SSPIF);           //
    SSPIF = 0;               //
}

PEN = 1;                     // send stop bit
while(PEN);                 //
}

void setup(void)
{
    unsigned long x;

    TRISB = 0xfe;            // RB0 (trig) is output
    PORTB = 0xfe;            // and starts low

    TRISC = 0xff;
    PORTC = 0xff;

    SSPSTAT = 0x80;
    SSPCON = 0x38;
    SSPCON2 = 0x00;
    SSPADD = 50;             // SCL = 91khz with 20Mhz Osc

    for(x=0; x<3000000L; x++); // wait for LCD03 to initialise
}

```