

BEAGLEBONE RS485 CAN CAPE EXPANSION BOARD



Description:

RS485 CAN CAPE is a BB Black's extended board, it comes with RS485 and CAN and other expansion interfaces, can communicate with RS485 or CAN device.

What's on the RS485 CAN CAPE



- BB Black connector: for connecting BB Black
- 2. CAN pinheader
- 3. CAN screw terminal
- 4. **RS485** pinheader
- 5. RS485 screw terminal
- 6. **DEBUG interface:** for debugging BB Black OR other connected modules
- Power expansion pinheader: for connecting external power supply
- 8. BB Black BOOT selection button
- 9. CAN transceiver
- 10. RS485 transceiver
- 11. Power indicator
- 12. BB Black UART TXD selection jumper
- 13. BB Black UART RXD selection jumper
- 14. RS485 transceiver enable jumper

