


UNIVERSAL A/C REMOTE

Model:KT-109 II

Manual Programing:

- 1-put batteries in the control and turn on the air-condition
 - 2-look at the name of the air-condition in the codes table and see its code
 - 3-Press set to choose the code you want,the code flashes on the remote screen
- Note: to move from one code to another press set another time
- 4-when you reach the code you need press enter or ok
 - 5-try the control



Auto Programing:

- 1-put batteries in the control and turn on the air-condition
- 2-press set rapidly when the condition start or stop or give buzzer press enter
- 3-try the control

Note: if some key didn't work continue to do the same operation until all keys work probably

برمجة يدوية:-

- 1-ضع البطاريات اشعل المكيف
 - 2-ابحث عن اسم المكيف في جدول الكودات
 - 3-اضغط كبسة set لاختيار الكود المطلوب
- ملاحظة: للانتقال من كود لآخر اضغط set مرة اخرى
- 4-عند الوصول الى الكود المطلوب اضغط enter او ok
 - 5-جرب الريموت

برمجة آلية:-

- 1-ضع البطاريات اشعل المكيف
- 2-اضغط كبسة set بشكل متتالي وعندما يعمل المكيف اضغط كبسة enter
- 3-جرب الريموت

ملاحظة: اذا لم تعمل جميع الازرار اكمل عملية البرمجة