

Camera Battery Sony

Model:NP-FR1



Specifications:

-Battery Type: Li-ion

-Voltage: 3.6V

-Capacity: 1220mAh

-Fit Models: Sony CyberShot DSC-F88, Sony CyberShot DSC-FX77, Sony CyberShot DSC-P100, Sony CyberShot DSC-P100/L, Sony CyberShot DSC-P100/LJ, Sony CyberShot DSC-P100/R, Sony CyberShot DSC-P100/S, Sony CyberShot DSC-P100PP, Sony CyberShot DSC-P120, Sony CyberShot DSC-P150, Sony CyberShot DSC-P150/B, Sony CyberShot DSC-P150/L, Sony CyberShot DSC-P150/LJ, Sony CyberShot DSC-P150/S, Sony CyberShot DSC-P200, Sony CyberShot DSC-P200 /B, Sony CyberShot DSC-P200/R, Sony CyberShot DSC-P200/S, Sony CyberShot DSC-P200B, Sony CyberShot DSC-P200R, Sony CyberShot DSC-T5, Sony CyberShot DSC-T30, Sony CyberShot DSC-T30/B, Sony CyberShot DSC-T30S, Sony CyberShot DSC-T50, Sony CyberShot DSC-T50/B, Sony CyberShot DSC-T50/R, Sony CyberShot DSC-T50S, Sony CyberShot DSC-V3.

Made in Japan