

Camera Battery Sony Model:NP-FH100



Specifications:

-Battery Type: Li-ion

-Voltage: 7.2V

-Capacity: 2300mAh

-Replacement For: NP-FH50, NP-FH60, NP-FH70

-Fit Models: DCR-SR32/E,DCR-SR52/E,DCR-SR72/E,DCR-SR190/E,DCR-SR290/E,DCR-SR30/E,DCR-SR50/E,DCR-SR70/E,DCR-SR90/E,DCR-SR42/E DCR-SR62/E,DCR-SR82/E,DCR-SR200/E,DCR-SR300/E,DCR-SR100/E,DCR-SR40/E,DCR-SR60/E,DCR-SR80/E,HDR-SR5/E,HDR-SR7/E,HDR-SR8/EDCR-DVD106/E,DCR-DVD109/E,DCR-DVD306/E,DCR-VD406/E,DCR-DVD506/E,DCR-DVD105/E,DCRDVD202/E,DCR-VD203/E,DCR-DVD205/E,DCR-DVD403/E,DCR-DVD404/E,DCR-VD406/E,DCR-DVD505/E,DCR-DVD92/E,DCR-DVD605/E,DCR-DVD705/E,DCR-DVD755/E,DCR-DVD805/E,DCR-DVD602/E, DCR-D653/E,DCR-DVD703/E,DCR-DVD803/E,DCR-DVD905/E,HDR-UX3/E,HDR-UX5/E,HDR-UX7/EDCR-HC27/E,DCR-HC28/E,DCR-HC37/E,DCR-HC45/E,DCR-HC20/E,DCR-HC22/E,DCR-HC24/E,DCR-HC30/E,DCR-HC32/E,DCR-HC35/E,DCR-HC39/E,DCR-HC40/E,DCR-HC42/E,DCR-HC44/E,DCR-HC46/E,DCR-HC85/E,DCR-HC94/E,DCR-HC96/E,DCR-HC26/E,DCR-HC36/E,DCR-HC21/E,HDR-HC3/E,HDR-HC5/E,HDR-HC7/E.

Made in China