

CAMERA BATTERY SONY

Model:NP-FH50 ORG



Specifications:

-Battery Type: Li-ion

-Voltage: 6.8V

-Capacity: 1050mAh

-Replacement For: NP-FH70, NP-FH100.

-Fit Models: HDR-SR5, HDR-SR7, HDR-SR8, HDR-SR10, HDR-SR11, HDR-SR12, HDR-HC3, HDR-HC5, HDR-HC7, HDR-HC9, HDR-UX3, HDR-UX5, HDR-UX7, HDR-UX10, HDR-UX20, HDR-CX6EK, HDR-CX7K, HDR-TG1, HDR-HC3, HDR-HC5, HDR-HC7, DCR-HC19, DCR-HC20, DCR-HC21, DCR-HC22, DCR-HC24, DCR-HC26, DCR-HC27, DCR-HC28, DCR-HC30, DCR-HC32, DCR-HC35, DCR-HC36, DCR-HC37, DCR-HC38, DCR-HC39, DCR-HC40, DCR-HC42, DCR-HC44, DCR-HC45, DCR-

HC46, DCR-HC47, DCR-HC48, DCR-HC52, DCR-HC54, DCR-HC62, DCR-HC85, DCR-HC94, DCR-HC96, DCR-DVD92, DCR-DVD105, DCR-DVD106, DCR-DVD108, DCR-DVD109, DCR-DVD202, DCR-DVD203, DCR-DVD205, DCR-DVD306, DCR-DVD308, DCR-DVD403, DCR-DVD404, DCR-DVD406, DCR-DVD408, DCR-DVD505, DCR-DVD506, DCR-DVD508, DCR-DVD602, DCR-DVD605, DCR-DVD608, DCR-DVD610, DCR-DVD653, DCR-DVD703, DCR-DVD705, DCR-DVD708, DCR-DVD710, DCR-DVD755, DCR-DVD803, DCR-DVD805, DCR-DVD808, DCR-DVD810, DCR-DVD905, DCR-DVD908, DCR-DVD910, HDR-UX3, HDR-UX5, HDR-UX7, DCR-SR30, DCR-SR32, DCR-SR40, DCR-SR42, DCR-SR45, DCR-SR46, DCR-SR50, DCR-SR52, DCR-SR60, DCR-SR62, DCR-SR65, DCR-SR70, DCR-SR72, DCR-SR80, DCR-SR82, DCR-SR85, DCR-SR90, DCR-SR100, DCR-SR190, DCR-SR200, DCR-SR220, DCR-SR290, DCR-SR300, HDR-SR5, HDR-SR7, HDR-SR8, HDR-SR10, HDR-SR11, HDR-SR1.